



KEYBOARD OVERVIEW

Escape: Aside from the usual, use this button to exit full screen view.

Right Arrow Button: Go to the next page in your browser history.

Full-Screen Shortcut: Hide the tabs and launcher in Full-Screen Immersive mode.

Screen Dimmer: Dim the screen.

Mute Button: Disable all noise from speakers.

Raise Volume: Increase the volume.

Left Arrow Button: Go to the previous page in your browser history

Reload Button: Reload your current page.

View All Windows: Show all windows in Overview mode.

Screen Brightener: Make the screen brighter.

Lessen Volume: Lower the volume.

Power Button: Use this to also perform a reset on the Chromebook.

KEYBOARD SHORTCUTS

Tabs & Windows Shortcuts			
Open a new tab	Ctrl + T	Reopen the last closed tab	Ctrl + Shift + T
Close the current tab	Ctrl + W	Close the current window	Ctrl + Shift + W
Page Shortcuts			
Scroll down the web page	Space Bar	Reload your current page	Ctrl + R
Go to top of page	Ctrl + Alt +	Right click a link	Press Alt and click a link
Go to bottom of page	Ctrl + Alt +	Save current page as a bookmark	Ctrl + D
Browser Shortcuts			
Open the History Page	Ctrl + H	Get help with your Chromebook	Ctrl + ?
Open the Downloads Page	Ctrl + J	Rotate screen 90 degrees	Ctrl + Shift + Reload
Text Editing Shortcuts			
Select everything on the page	Ctrl + A	Go to beginning of document	Ctrl + Search +
Page Up	Alt +	Copy selected content to clipboard	Ctrl + C
Page Down	Alt +	Copy selected content from clipboard	Ctrl + V
Go to end of document	Ctrl + Search +	Undo your last action	Ctrl + Z

TOUCHPAD SHORTCUTS

Command	Description of Operation
Right-Click	Press or tap the touchpad with two fingers. You can also press Alt , then click with one finger.
Scroll	Place two fingers on the touchpad and move them up and down to scroll vertically, or left and right to scroll horizontally.
Move between pages	To go back to a page you were just on, swipe left with two fingers. To go forward to a page you were just on, swipe right with two fingers.
See all open windows	Swipe up or down with three fingers.
Switch between tabs	If there are multiple tabs open, you can swipe right and left with three fingers to quickly change between tabs.
Drag and drop	Click and hold the item to move. While holding, move the item. Release your finger to drop the item in its new location.

TOUCHPAD TROUBLESHOOTING

<p>Change Touchpad Settings:</p> <ol style="list-style-type: none"> 1. Click "Status," where the picture appears 2. Click Settings. 3. In the "Device" section, adjust the sliders to set your touchpad or mouse speed 4. Click Touchpad Settings to: turn tap-to-click on or off, swap your primary mouse button, choose traditional or Australian scrolling. 5. When finished, click OK. 	<p>Fix Touchpad Problems:</p> <p>- If your touchpad stops working, try the following steps:</p> <ol style="list-style-type: none"> 1. Make sure there is no dirt or dust on the touchpad. 2. Touch ESC key several times. 3. Drumroll your fingers on the touchpad for ten seconds. 4. Restart your Chromebook. 5. If the issue persists, contact your teacher librarian to submit a work order to LIS.
---	--